

# SHOUT tsm QUICK START GUIDE

Support Phone#: 571-833-2169  
[Support@Nalresearch.com](mailto:Support@Nalresearch.com)  
 451-22012-002A  
 2023-03-31

**DEVICE DESCRIPTION OVERVIEW:** The SHOUT tsm is a handheld, global, satellite personal tracker designed to operate with the Iridium low-Earth orbit satellite network. It provides location information determined by the selected receiver. It comprises an Iridium 9603 transceiver module; a Military GPS receiver; a GNSS receiver; an embedded 3800 mA-Hr battery, an Iridium antenna, an L1/L2 GNSS/M-Code antenna; and an IP67 screen display w/ protective overlay. The SHOUT tsm allows only SBD connectivity to the Iridium satellite network.

**IMPORTANT:** The SHOUT tsm antennas must have a clear view of the sky during transmission.



## DEVICE DESCRIPTION

- ❑ **Micro DB-15 Connector Port:** The micro DB-15 connector port is IP-67 compliant. It is mounted on the side of the device above the USB-C connector port, and supports:
  - EKMS-308 Compliant Key-Fill
  - SHOUT Bidirectional Data Transfer Mode supporting Position-Only and Precise-Time transfers.
- ❑ **USB-C Connector Port:** The USB-C connector port is IP-67 compliant, and is mounted on the side of the SHOUT tsm device. It is used to power the device, charge the embedded battery, and data usage.

## CHARGING BATTERY


- ❑ Fully charge the SHOUT tsm using a USB-C cable.  
 NOTE: NAL Research recommends an AC adapter that is capable of 2.5A at 5V for fastest charging speed.

## EMERGENCY MODE

- ❑ **Activate:** Slide the Emergency Switch Cover, and quickly press and release the Emergency button to trigger emergency tracking. When emergency tracking is active, the Emergency LED illuminates.
- ❑ **Deactivate:** Press/hold the Emergency button longer than three (3) seconds to take the SHOUT tsm out of emergency tracking.


## POWER-ON/NAVIGATE TO HOME SCREEN

1. Press the **Power** button (2-3 seconds).
2. Press **Press to Unlock** button.  
 The Home screen displays.



## Select Receiver

1. Press **Setting** on the Home screen.  
The Setting screen displays.
2. Press **PNT**.  
The PNT Setting screen displays.
3. Press **PNT Selection**.  
The PNT Selection screen displays.
4. Select **Commercial** or **MIL**.



## Display MIL Status

1. Select **Utilities** from the Home screen.  
The Utilities screen displays.
2. Select **MIL**.  
NOTE: If the MIL encryption keys are not loaded, make the appropriate contact to load the encryption keys.

